


Rainmatic® Timers

Mechanical


5200



Operating Controls

- A** Water Connection
- B** Arrow
- C** Timer Control Dial
- D** Hose Connector

5200 Automatic Water Shut-Off



Attach Automatic Water Shut-Off to your faucet. Push in and turn white cap counter-clockwise to set timer from 1/2 to 3 hours. Match time on label to arrow on cylinder. Turn on water. Timer will automatically shut water off after the time you set. Actual time will vary depending on water pressure and type of sprinkler used.

CAUTION: Detach Automatic Water Shut-Off from faucet during freezing weather. This product intended for outdoor watering only. Do not use with water exceeding 100°F (38°C) or with pressure exceeding 100 psi. The Automatic Water Shut-Off is not intended for use in low water flow applications such as soaker hose or drip systems. Avoid excessive pulling or tugging on the hose as damage to the timer may occur.

Watering Chart

Actual Time Of Operation Using Different Sprinklers (average water pressure at 40 psi)						
Timer Dial Setting	1/2 hr	1 hr	1-1/2 hr	2 hr	2-1/2 hr	3 hr
Average Oscillator (medium flow)	1/2 hr	1 hr	1-1/2 hr	2 hr	2-1/2 hr	3 hr
Average Whirler (fast flow)	1/3 hr	2/3 hr	1 hr	1-1/3 hr	1-1/2 hr	2 hr
Average Impact (slow flow)	2/3 hr	1-1/3 hr	2 hr	2-2/3 hr	3-1/3 hr	4 hr

The Automatic Water Shut-Off may vary depending on the water pressure and sprinkler being used.