


Rainmatic® Timers TimerMate®

5210




Operating Controls

- A** Water Connection
- B** Flow Indicators
- C** Hose Connectors

5210 TimerMate®

- 1) Attach your TimerMate to the base of any Nelson RainMatic® Electronic Water Timer.
- 2) Attach hoses to the unit. Recommend removing TimerMate if only one hose is needed.
- 3) Turn on water at faucet and program your Nelson Electronic Water Timer according to the instructions included with the unit. Allow a minimum of 15 seconds between cycle times to allow TimerMate to alternate direction of water flow. This time will vary depending on the sprinkler type and location.
- 4) Make sure any shut-off valves between the TimerMate and the hose end are open. Flow will not alternate if hose-end shut-off valves or sprinkler flow controls are closed. TimerMate will not alternate water flow with nozzles that are turned on and off.
- 5) Flow indicator shows the water flow direction when the timer is on. When timer is off and water is not flowing, flow indicator shows the next direction of flow. Flow will continue to change directions each time water is shut off either at the faucet or by the timer.




Note: TimerMate is most efficient and practical when used with an electronic timer. However, it may be used without a timer.


Caution: Detach TimerMate and Nelson RainMatic® Electronic Water Timer from faucet during freezing weather. This product intended for outdoor watering only. Do not use with water exceeding 100°F (38°C) or with pressure exceeding 80 psi. Avoid excessive pulling or tugging on the hose as damage to the TimerMate may occur.

Alternate Arrangement

This arrangement may be used if you are unable to attach TimerMate to electronic timer, or if it is undesirable to run two hoses directly from the timer/TimerMate unit (from inside a garage or other building, for example).



The Possibilities Are Endless



Now you can benefit from the convenience of multi-zone electronic timers without the investment. Simply choose two areas – lawn and flower bed or shrubs; front yard and back yard; drip system and lawn – set the timer and TimerMate does the rest.